



## Conestoga Wagon

### PARTS LISTS MS6002

PART #	ITEM	QUANTITY	DESCRIPTION/NOTES
<b>MISCELLANEOUS FITTINGS AND MATERIAL</b>			
WP6002	Wheels hub	4	
WP0993	Nails	100	
WPANC123110	19 gauge wire	4"	Cut into 2" pieces - used to make the strops
WP0434	Eyebolts	10	
WP0953	Split rings	12	
WP0409-A	18 ga. escutcheon pins	14	
WP0440	16 ga. escutcheon pins	10	
WP0481	Chain	24"	
WP1224	Rigging line 0.25mm	2 yds	
WPDRL22651	Drill bit #51	1	
WPDRL22655	Drill bit #55	1	
WPDRL22667	Drill bit #67	1	
WPDRL22672	Drill bit #72	1	
WP160K-12	Rod - 1/32" dia.X 12"	3	
WP1700	Photo etched	1	Brass
WP0567	Sail cloth 36" x 18"	1	

#### WOOD DOWELS

Note: All dowels are Beech unless otherwise noted. Dowels are supplied in lengths as noted. Cut to length as required.

WP5101-24	1/8" x 12"	1
WP5103-24	3/16" x 12"	1

#### WOOD STRIPS, SHEETS, AND BLOCKS

Note: All wood is Basswood or Limewood (European Basswood) unless otherwise noted. Wood strips, sheets, and blocks are supplied in lengths as noted. Cut to length as required.

##### STRIPS

WP3626-24	3/32" x 1/8" x 24"	1
WP3622-24	1/16" x 3/16" x 24"	4
WP3631-24	1/8" x 1/8" x 24"	1

## LASER-CUT WOOD PARTS

Note: All Laser-Cut wood is Basswood or Limewood European Basswood unless otherwise noted.

WP4622-B	<u>1/4" Thick</u>	<u>1</u>
	CW1	
WP4631-A	<u>3/16" Thick</u>	<u>1</u>
	CW2	
WP4613-C	<u>1/8" Thick ply</u>	<u>1</u>
	CW3	
WP4607-D	<u>1/16" Thick</u>	<u>1</u>
	CW4	
WP4607-E	<u>1/16" Thick</u>	<u>1</u>
	CW5	
WP4607-F	<u>1/16" Thick</u>	<u>1</u>
	CW6	
WP4655-H	<u>1/32" Thick ply</u>	<u>1</u>
	CW7	
WP4620-I	<u>3/16" Thick ply</u>	<u>1</u>
	CW8	
WP3157-J	<u>1/32" Thick Gasket material</u>	<u>1</u>
	CW9	
WP4640-K	<u>5/32" Thick Bass</u>	<u>1</u>
	CW10 Spokes	
WP4621-L	<u>1/4" Thick Ply</u>	<u>1</u>
	CW11 Wheel rim	

## PLANS AND INSTRUCTIONS

WP6002MB	Instruction Manual	1	
WPPL6002-A	Plans - 5 sheets		1
WPPL6002-B	Wheel patterns template	1	
WPPL6002	Parts List	1	

### NOTE:

- Before painting hubs spray with aluminum primer.
- Plan sheet 1 of 5 and instructions page 7. Detail 1-7 rear carriage assembly B-8 should read B-30
- Laser board CW-3 part #66 axe handle should be #69
- The strops shown as 0992 in detail 2-1 now need to be fashioned from the supplied 19 gauge wire.